

## ADVANTECH® SUBFLOORING

### MANUFACTURER

Huber Engineered Woods LLC  
 10925 David Taylor Drive, Suite 300, Charlotte, NC 28262  
 800.933.9220 • Technical Service: 800.933.9220 x2716  
 ZIPSystem.com • HuberArchitectLibrary.com

### BASIC USE AND APPLICATIONS

AdvanTech® subflooring is a high-performance engineered panel designed to replace plywood and commodity oriented strand board (OSB) subfloor panels. Fabricated in highly-controlled production facilities utilizing advanced resin technology, AdvanTech subflooring panels exhibits higher bending strength, and greater dimensional stability. AdvanTech subflooring panels exceeds the code minimums used by other subflooring panels, providing users with a more stable floor and builders with a more reliable product that retains its qualities under environmental exposure during construction.

AdvanTech subflooring panels are nailed or screwed to floor framing members; long edges are precision tongue-and-groove, and the panel surface is fully sanded. Using a polyurethane or solvent based subfloor adhesive is recommended for optimal performance. Panels are available in five performance categories for a wide range of applications.

### AVAILABLE SIZES AND RATINGS

AdvanTech subflooring panels are available in nominal 4' by 8' foot\* sheets in the following DOC PS 2 Sheathing span ratings and performance categories. All panels are Structural I and Exposure 1 rated.

- 20 oc, 19/32 Performance Category
- 24 oc, 23/32 Performance Category
- 32 oc, 7/8 Performance Category
- 32 oc, 1 Performance Category
- 48 oc, 1-1/8 Performance Category

Third party independent compliance testing of AdvanTech subflooring performed by PFS TECO.

\* face dimensions are approximately 47-1/2" x 95-7/8"



AdvanTech® Subflooring Benefits	
Excellent Design Strength	Provides a high-density, stiff floor for lasting stability and toughness
Excellent Design Stiffness	Outperforms plywood and commodity OSB sheathing to minimize floor bounce and squeaks
Excellent Moisture Resistance	Minimizes swelling, warping, cupping, and delamination
Higher Density	Greater nail and screw holding power

### GENERAL SUSTAINABLE DESIGN CONTRIBUTIONS

- Low-Emitting Material: No added urea formaldehyde or VOC constituents
- Sustainable Forestry Initiative Certified Wood: Harvested, transported, manufactured, and distributed utilizing sustainable practices
- Renewable Forest Resources: Composed of primarily young growth bio-based resources
- Materials: Made in the United States at one of five manufacturing facilities

### POTENTIAL LEED CREDIT CONTRIBUTION

- Credit IEQ 4.4 Low-Emitting Materials, Composite Wood and Agrifiber: AdvanTech contains no added urea formaldehyde
- Credit MR 5.1 or 5.2 Regional Materials: Materials harvested, processed, and manufactured within 500 miles of project site.
- Credit MR 2.2 Environmentally Preferable Products – Local Production (LEED for Homes)

AdvanTech® Subflooring Physical Properties** vs. OSB/Plywood		
Bending Stiffness, EI (lbf-in/ft)	AdvanTech: 383,800	OSB/Plywood: 300k/330k
Bending Strength, F <sub>b</sub> S (lbf-in/ft)	AdvanTech: 1,250	OSB/Plywood: 770
** For 23/32 perf cat thick panel, primary strength axis. For design capacities, section properties, and equivalent specific gravity values of AdvanTech, refer to ICC-ES ESR-1785. For OSB and Plywood values, refer to 2012 APA Panel Design Specification.		

## SUBSTRATE

Before beginning installation, verify framing is properly spaced and aligned to support panel edges. Install AdvanTech subflooring in accordance with:

- AdvanTech® subflooring installation instructions
- ICC-ES ESR-1785
- Requirements of authorities having jurisdictions

Tongue and groove edges are self-spacing; square edge panel ends should be spaced 1/8" (3 mm) apart. For more information on panel spacing or panel joints, reference Tech Tip *Temporary Expansion Joints with AdvanTech Subflooring*.

## INSTALLATION METHODS

AdvanTech subflooring panels can be installed over wood or cold-formed metal floor framing. Install over wood using nail or screw fasteners. For metal framing applications, reference Tech Tip *Installing AdvanTech over Metal Framing*. Subfloor adhesive is recommended for all applications.

**Fasteners:** Install fasteners approved by applicable building code(s). Fasteners should penetrate wood members minimum 1 inch (25.4 mm). Install fasteners 3/8" (9.5 mm) to 1/2" (12.7 mm) from panel edges. Space fasteners 6-inches (152 mm) on-center on supported panel ends and 12-inches (305mm) on-center at intermediate support locations. AdvanTech subflooring panels have a printed fastening guide for 16-inch (406 mm), 19.2-inch (488 mm), and 24-inch (610 mm) on-center fastener locations on the panel surface.

**Adhesives:** Polyurethane or solvent-based subfloor adhesives conforming to APA AFG-01 or ASTM D3498. For projects requiring low-VOC adhesives, consult adhesive manufacturer for compliant products. Apply a single 1/4" inch (6 mm) bead on floor framing, and double bead on framing members supporting ends of two panels.

## FINISHED FLOORING APPLICATIONS

- Typical Residential Carpet and Pad: May be installed directly over AdvanTech subflooring
- Commercial Carpet, VCT, Sheet Vinyl: Minimum 1/4 inch (6 mm) thick plywood underlayment per flooring manufacturer recommendations
- Hardwood: Apply #15 felt or equivalent per flooring manufacturer recommendations
- Ceramic Tile: Apply underlayment as required by ANSI A108. Install tile and underlayment in accordance with TCNA installation methods
- Gypsum Concrete Underlayment: Apply directly over primed AdvanTech subflooring following underlayment manufacturer's instructions

## STORAGE AND HANDLING

Store and handle products according to AdvanTech subflooring Installation Manual. Support panel bundles off the ground. Cover stored panels with weatherproof protective material; allow sides of protective material to remain loose to assure adequate air circulation. In high moisture conditions, cut bundle banding to prevent edge damage to the panels.

## AVAILABILITY

Huber Engineered Woods' AdvanTech subflooring panels are manufactured at multiple locations in the U.S. and are available through distributors nationwide. Visit [advantechperforms.com](http://advantechperforms.com) or contact Huber Engineered Woods for a retailer near you.

## WARRANTY

AdvanTech subflooring panels are guaranteed not to delaminate nor require sanding for 500 days after purchase in addition to a Limited Lifetime warranty against manufacturing defects. See the AdvanTech subflooring Limited Warranty for full details.

## NOTES AND LIMITATIONS

When a building's uninterrupted flooring length or width exceeds 80- feet, designers should incorporate expansion joints to accommodate the cumulative effect of incremental panel expansion. This is an industry recommendation and is not unique to AdvanTech subflooring.

- Do not paint with water-based coatings such as latex paints
- Do not use water-sealers
- Do not use in permanent exterior applications
- Do not use salt-based ice melts

## TECHNICAL SERVICE

Detailed information including specifications, product literature, test reports, installation instructions, and special applications are available through Huber Engineered Woods. Please visit [huberwood.com](http://huberwood.com) or call 800.933.9220 Ext. 2716 to speak to a technical representative.

## AVAILABLE RESOURCES

Section 06 16 00 SHEATHING guide specification for AdvanTech subflooring and sheathing products in CSI 3-part format is available at [HuberWood.com](http://HuberWood.com).

© 2016-2020 Huber Engineered Woods LLC. AdvanTech, FLAT OUT BEST, the AdvanTech logo and design are trademarks of Huber Engineered Woods LLC. Huber is a trademark of J.M. Huber Corporation. HUB 3074 REV 08/29/24